TABLE OF CONTENTS

Warranty	Page 2
Safety Symbols	Pages 4-5
Safety Instruction	Pages 6-10
Unpacking	Page 11
Description	Pages 12-14
Assembly	Pages 14-17
Operation	Pages 18-29
Maintenance	Pages 30-31
Accessories	Pages 32-33
Parts List	Pages 34-36

CRAFTSMAN ONE YEAR LIMITED WARRANTY

FOR ONE YEAR from the date of purchase, this product is warranted against any defects in material or workmanship. With proof of purchase, defective product will be replaced free of charge.

For warranty coverage details to obtain free replacement, visit the web site: www.craftsman.com

This warranty is void if this product is ever used while providing commercial services or if rented to another person.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears Brands Management Corporation, Hoffman Estates, IL 60179

SAVE THESE INSTRUCTIONS!

READ ALL INSTRUCTIONS!