



# Smart Lawn Connect Kit Installation Instructions

Congratulations on purchasing a Craftsman Smart Lawn Connect Kit. The **Craftsman Smart Lawn Connect Plug** will easily plug in to the back side of your Craftsman Rider's **Ignition Switch** located on the dashboard.



These instructions apply to a majority of Craftsman Riding Mowers manufactured from 2010 to Present. Read through the entire instruction sequence before beginning installation. For instructions for your unit, or more details, please go to [craftsman.com/connectkit](http://craftsman.com/connectkit)





**WARNING** Before performing any maintenance or repairs, disengage PTO, set parking brake, stop engine and remove key to prevent unintended starting.

## Installation Guide:

1. Note the location of the **Ignition Switch** (ON/START/OFF switch) on your dash. Depending on your product model, the switch will look like **X** or **Y** below. Note location of retainer prongs for Step 3B below.



2. Open the hood of your Craftsman Rider and locate the **Wire Harness Connector** that is attached to the back side of the **Ignition Switch** (refer to illustration below).



Exposed Wire Harness Connector

Your part may vary slightly in appearance.

3. There are two options for disconnecting the **Wire Harness Connector** from the back of the **Ignition Switch**:  
**A** Leave **Ignition Switch** in place and unplug **Wire Harness Connector** directly from the underside of the dash (see illustration above).  
**OR** (Continued on next page)





# Smart Lawn Connect Kit Installation Instructions

**3B** Remove the **Ignition Switch** (refer to illustrations **X** or **Y** on first page) by reaching under dash and squeezing the **Retainer Prongs** (see illustration below).


**4** Connect the **Wire Harness Connector** to the **Craftsman Smart Lawn Connect Plug** (see illustration below).

Then unplug the **Wire Harness Connector**.



**5** Connect the **Craftsman Smart Lawn Connect Plug** with the **Ignition Switch** (see illustration below).

Assembly is complete when the Craftsman Smart Lawn Connect Plug is sandwiched between the other two components.



**6** If **Ignition Switch** has been removed, align the **Ignition Switch** with hole, and push into dash, ensuring that retainer prongs click securely into the dashboard recess.

For more detailed assembly instructions if needed for your specific model, please refer to the following Craftsman link: [craftsman.com/connectkit](http://craftsman.com/connectkit)

If you have further questions, call our Craftsman help line at **1-888-331-4569**

Once assembly is complete please download the **FREE Craftsman Smart.Lawn App** to begin using all of the new connectivity features of your Craftsman rider!



\*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by (Sears Brands Management Corporation) is under license. Other trademarks and trade names are those of their respective owners. †Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Google Play and Android are trademarks of Google Inc. Sears Brands Management Corporation, Hoffman Estates, IL 60179

Universal Keywords: Div71 Src917 Husqvarna Mechtech

Document Specific Keywords: Installation Instructions

Date: 020617

Document Name: 769-11906

Subject: MTD Husqvarna Smart Lawn Connect Installation Instructions

Models: 917.203800 917.254310 917.288630 917.203801 917.254320 917.288631  
917.203810 917.254330 917.288610 917.203820 917.255810 917.288662 917.203830  
917.255830 917.288671 917.203840 917.255840 917.288672 917.203850 917.280080  
917.289140 917.203860 917.280083 917.289213 917.203861 917.280084 917.289223  
917.203900 917.280350 917.289245 917.203901 917.288514 917.289233 917.203910  
917.288515 917.289255 917.203911 917.288517 917.289272 917.203920 917.288520  
917.289283 917.203921 917.288522 917.289344 917.203930 917.288526 917.289362  
917.204021 917.288530 917.289452 917.204031 917.288533 917.289453 917.204080  
917.288560 917.289472 917.204090 917.288561 917.289482 917.204130 917.288563  
917.289550 917.204170 917.288570 917.289551 917.250220 917.288572 917.289904  
917.250222 917.288573 917.289912 917.250230 917.288580 917.986411 917.250231  
917.288582 917.986421 917.250240 917.288583 917.986431 917.250241 917.288611  
917.986441 917.250250 917.288612 917.986451 917.250811 917.288613 917.280020  
917.250820 917.288620 917.280023 917.250830 917.288623 917.250841 247.20372  
247.20377 247.20438 247.203721 247.203771 247.204400 247.203722 247.203772  
247.204420 247.203723 247.203773 247.204420 247.203724 247.203774 247.204390  
247.203725 247.203775 247.204430 247.203726 247.203776 247.204440 247.20373  
247.20379 247.204450 247.203731 247.203791 247.204470 247.203732 247.20400  
247.28880 247.203733 247.20410 247.28902 247.203734 247.20411 247.28904  
247.20374 247.20418 247.28905 247.203741 247.204181 247.28911 247.203742  
247.204182 247.28919 247.203743 247.20419 247.28933 247.203744 247.204191  
247.28888 247.20375 247.204200 247.288881 247.203751 247.204201 247.28980  
247.203752 247.204220 247.28981 247.203753 247.204221 247.28984 247.203754  
247.204240 247.28672 247.20376 247.204241 247.28901 247.203761 247.25003  
247.20400 247.20410 917.27390 917.27394 247.27038 247.27042 247.27049  
247.27044 247.27039 247.27055 247.27048 247.27047 917.27778 917.27773  
917.27771 917.27779 247.27050 247.27052 247.27054 917204090 917288561  
917289483 917204130 917288563 917289550 917204170 917288570 917289551  
917250220 917288572 917289904 917250222 917288573 917289912 917250230  
917288580 917986411 917250231 917288582 917986421 917250240 917288583  
917986431 917250241 917288611 917986441 917250250 917288612 917986451  
917250811 917288613 917280020 917250820 917288620 917280023 917250830  
917288623 917250841 24720372 24720377 24720438 247203721 247203771  
247204400 247203722 247203772 247204420 247203723 247203773 247202420  
247203724 247203774 247204390 247203725 247203775 247204430 247203726

247203776 247204440 24720373 24720379 247204450 247203731 247203791  
247204470 247203732 24720400 24728880 247203733 24720410 24728902  
247203734 24720411 24728904 24720374 24720418 24728905 247203741  
247204181 24728911 247203742 247204182 24728919 247203743 24720419  
24728933 247203744 247204191 24728888 24720375 247204200 247288881  
247203751 247204201 24728980 247203752 247204220 24728981 247203753  
247204221 24728984 247203754 247204240 24728672 24720376 247204241  
24728901 247203761 24725003 24720400 24720410 91727390 91727394 24727038  
24727042 24727049 24727044 24727039 24727055 24727048 24727047 91727778  
91727773 91727771 91727779 24727050 24727052 24727054 whatsnew

LIS Internal Use Only