

## TABLE OF CONTENTS

Warranty Statement.....	Page 2	Operation .....	Page 12
Safety Instructions .....	Pages 3-6	Service and Maintenance.....	Pages 13-15
Slope Guide .....	Page 7	Español.....	Page 17
Assembly.....	Pages 8-11	Service Number.....	Back Cover

## WARRANTY STATEMENT

### CRAFTSMAN LIMITED WARRANTY

FOR ONE YEAR from the date of sale this product is warranted against defects in material or workmanship.

WITH PROOF OF SALE, a defective part will be replaced free of charge. If a replacement part is unavailable, the product will be replaced with one of equal value.

For warranty coverage details to obtain free replacement, visit the web page: [www.craftsman.com/warranty](http://www.craftsman.com/warranty)

This warranty does not cover the cloth bag or high lift blades, which are expendable parts that can wear out from normal use within the warranty period.

This warranty is void if this product is ever used while providing commercial services or if rented to another person.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Sears Brands Management Corporation, Hoffman Estates, IL 60179

## MODEL NUMBER

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

Date of Purchase \_\_\_\_\_

Record the model number, serial number,  
and date of purchase above.