



*Supplemental Assembly Instructions*

If you are installing the 52" Rail System on a saw with the Mobile Base, PLEASE notice the 2 - 8 mm cap screws (A) referred to in Step #12 of the manual and shown in Fig. 6 on page 3, are used for assembly purposes only. As you adjust the legs on the Extension Table the head of the cap screws may fall below the slot in the table top. This will not effect the performance or stability of your saw.

